

INSECT KILLER WITH UV LIGHT



HIGH VOLTAGE! THE UNIT GENERATES HIGH VOLTAGE DURING OPERATION. • HOCHSPANNUNG! DAS GERÄT ERZEUGT HOCHSPANNUNG IM BETRIEBSZUSTAND. • MAGASFESZÜLTSGÉ! A KÉSZÜLÉK MAGAS FESZÜLTSGÉT GENERÁL MŰKÖDÉS KÖZBEN. • VYSOKÉ NAPĚTÍ VÝROBK PRACUJE NA PRINCÍPU VYSOKÉHO NAPĚTÍ. • VYSOKÉ NAPĚTÍE! VÝROBK PRACUJE NA PRINCÍPE VYSOKÉHO NAPĚTIA. • WYSOKIE NAPIĘCIE! PODCZAS PRACY URZĄDZENIE GENERUJE WYSOKIE NAPIĘCIE. • VISOKI NAPON! UREDAJ PRI RADU STVARA VISOKI NAPON. • TENSIUNE INALTĂ! APARATUL GENEREAZĂ TENSIUNE INALTĂ ÎN TIMPUL FUNCȚIONĂRII.

INSECT KILLER - WITH UV LIGHT PRODUCT CODE: 55620BK/55620WH

USER MANUAL

Hanging or table insect trap with large surface area and brightness. Thanks to the stable base it can be placed on a table, shelf, but can also be hung up to 2-3 meters high. Unpleasant insects (such as mosquitoes) and small flies are attracted to ultraviolet light. On their way to the light source, they fly at the live electrode and it kills them quickly, painlessly and hygienically.

Light source:	16 pcs UV LED
Efficiency:	2 W
Plug type:	EURO mains (230 V, 50/60 Hz, 5A)
Input voltage:	230 V
Net voltage:	aprox. 600 V
Cable length:	80 cm
Size:	300 x 265 x 70 mm
Weight:	520 g

INSTALLATION: 1. Install the unit at a height of 1.5 m to 3 m above the floor or use the pins to pry it to the ground. Do not install too close to other light sources. For effective protection, the appliance must be installed in the darkest part of the room. When installing, be sure to place at a sufficient distance from foodstuffs and people so that insects do not come close to them.

SAFETY INSTRUCTIONS: 1. Store the appliance in a place not accessible by children. 2. When installing, use only with the hanging ring, never hang it by the cable. 3. Hang up to high altitude where kids cannot reach it. 4. The appliance is not suitable for use in commercial facilities (barn, stable) and in commercial units (butcher shop, food processing plants, shops). 5. Never use the appliance if it is damaged. 6. Never use the device of other purposes than it was originally intended. 7. This appliance is not intended for use in rooms where flammable liquids, explosive gases or dusts may be present. 8. Never touch the inside of the product with other items. 9. Never repair the appliance, leave it up to a maintenance service! 10. Follow the instructions in this manual for cleaning and maintenance.

WARNING: Do not use in or near stables, barns or similar buildings (fire hazard)
Caution: High Voltage! The unit generates high voltage during operation. To hang up, use the hanging ring on the device and hook it to a hard-to-reach location.

CLEANING, CARE: Before cleaning, switch off the appliance! Then remove the top cover. (1/4 turn counter-clockwise. Turn the device over to the side and dump the dead insects. It is recommended to empty the container weekly! If the insects have stuck to the net surrounding the bulb, use a soft brush to remove them. Remember to reattach the lower housing after emptying. It is forbidden to use the appliance without the lower housing part. For safety reasons, never use water or other liquids for cleaning. Only use a dry, lint-free cloth and a dry soft brush.

GENERAL SAFETY INSTRUCTIONS: Important: The manufacturer / distributor does not warrant any damages caused by failure to follow the operating instructions. - Only operate the device with the correct voltage. - If you need to repair the appliance, always use original parts only to avoid serious damage. - Check the power cord of the machine, do not use the damaged cable. Contact your service or representative for access to the original non-defective cable for operation. - Repair, maintenance eg. fuse replacement, etc., should be done only by suitably trained personnel. - Important note! The manufacturer / distributor shall not be liable for damages resulting from operating or connection errors. - Before connecting to a wall outlet, always check that the device is compatible with the mains voltage. (for indoor use only) - This device may be hazardous to persons with reduced physical, mental or mental capabilities or children or people lacking the experience and knowledge of using the device. For their safety, always use the device in the presence of a responsible person. - The appliance is not a game, so keep it away from children or leave children unattended!

GENERAL INFORMATION: 1. Keep electrical devices and their packaging away from children! 2. Ensure the disposal of end-of-life equipment and packaging materials in an environmentally-friendly manner. 3. Operate the device only as described in this manual. 4. Due to continuous product development, technical data and appearance may change!

The manufacturer / distributor shall not be liable for damages resulting from operating or connection errors. Especially when it is proven that the product or electronics has been modified, remanufactured, the original parts have not been used for repair, or if the damage was due to negligence or damage.

ENVIRONMENTAL PRECAUTIONS: If the product is defective or at the end of its service life do not place it in household waste. Please visit the collection point for electronic waste and place the device there. The icon on the product, its packaging, and the icon in this manual will also alert you of this. The materials are reusable, as indicated. By re-utilizing old appliances, we contribute significantly to the protection of the environment.

ELEKTROMOS ROVARCSAPDA UV FÉNNYEL TERMÉKKÓD: 55620BK/55620WH

HASZNÁLATI UTASÍTÁS

Nagy felülettel és fényerővel rendelkező, felakasztható vagy asztali rovarcsapda. A stabil talpazatnak köszönhetően elhelyezhető asztalon, polcon, de akár 2-3 méter magasba felakasztva is használható. A kellemetlen csípő szárnyas rovarokat (pl. a szönyöggökat) és kis légyféléket az ultraibolya fény vonzza. Útjukon a fénycső felé nekirepülnek a fényszűrés alatt lévő elektródának, és az gyorsan, fájdalommentesen és higiénikusan megöli őket.

Fényforrás:	16 db UV LED
Teljesítmény:	2 W
Csatlakozó típusa:	EURO Hálózati (230 V, 50/60 Hz, 5A)
Bemeneti feszültség:	230 V
Feszültség a hálóban:	kb. 600 V
Kábel hossza:	80 cm
Méret:	300 x 265 x 70 mm
Súly:	520 g

BEÜZEMELÉS: 1. Telepítse a készüléket 1 m – 3 m magasságra a padlószinttől. Ne telepítse túl közel egyéb fényforrásokhoz. A hatékony védelem érdekében a helyiség legötöbbszörében kell beüzemelni a készüléket. A szerelésnél legyen tekintettel arra, hogy elegendő távolságban helyezze el élelmiszerektől, emberektől hogy a rovarok ne kerüljenek ezek közelébe.

BIZTONSÁGI UTASÍTÁSOK: 1. Gyerekek által nem elérhető helyen tárolja a készüléket. 2. Felszereléskor kizárólag az akasztóval rögzítse. 3. Kellő magasságra függesztse fel, ahol a gyerekek biztosan nem érhetik el. 4. A készülék nem alkalmas gazdasági létesítményekben (csűr, pajta, istálló), továbbá kereskedelmi egységekben (hentes üzlet, élelmiszer feldolgozó üzemek, üzletek) történő használatra. 5. Soha ne használja a készüléket, ha az sérült. 6. Soha ne használja a készüléket mátra, mint amire eredetileg kitalálták. 7. A készülék nem alkalmas olyan helyiségben történő használatra, ahol gyúlékony folyadékok, robbanó gázok vagy porok lehetnek. 8. Soha ne nyúljon a készülékbe egyéb tárgyakkal. 9. Soha ne javítsa a készüléket, bízta azt szakszervizrel! 10. Kövesse a használati utasításban foglalt teendőket a tisztítás, karbantartás során.

FIGYELMEZTETÉS: Ne használja istállókban, csűrökben vagy hasonló épületekben vagy annak közelében (tűzveszély) Figyelem: Magasfeszültség! A készülék magas feszültséget generál működés közben. Felakasztáshoz használja a készüléken található fogantyút, és akassza nehezen elérhető helyre.

TISZTÍTÁS, APÓLÁS: Mielőtt hozzáfogna a tisztításhoz, kapcsolja ki a készüléket! Az edény ürítése hetente ajánlott! Ha a rovarok hozzáragadtak az láttól körülvéő hálóból, puha kefével távolítsa el őket. Biztonsági okokból soha ne használjon vizet vagy egyéb folyadékot a tisztításhoz. Kizárólag száraz, nem foszló textillal és száraz, puha kefével tisztítsa.

ÁLTALÁNOS BIZTONSÁGI UTASÍTÁSOK: Fontos: A használati utasítás be nem tartása miatt keletkezett károkért a gyártó / forgalmazó nem vállal garanciát. - Amennyiben javítani kell a készüléket, minden esetben kizárólag eredeti alkatrészeket használjon, hogy elkerülje a komolyabb károsodásokat. - Fontos! Az üzemeltetési vagy csatlakoztatási hibákból eredő károkért a gyártó / forgalmazó nem vállal felelősséget. - A készülék használata veszélyes lehet olyan személyek számára akik, csökkent fizikai, szellemi, mentális képességekkel rendelkeznek, vagy gyerekek, vagy nem rendelkeznek kellő tapasztalattal és tudással az eszköz használatát illetően. - Az ő biztonságuk érdekében minden esetben kizárólag felelős személy jelenlétében használják a készüléket. - A készülék nem játék, ezért gyerekektől tartsa távol, illetve ne hagyja a gyerekeket felügyelet nélkül!

ÁLTALÁNOS INFORMÁCIÓK: 1. Az elektromos berendezéseket, valamint azok csomagolóanyagát tartsa távol gyerekektől! 2. Gondoskodjon az elhasználtótt berendezések, valamint azok csomagolóanyagának környezetbarát módon történő megsemmisítéséről! 3. Az eszköz kizárólag a használati utasításban leírt módon üzemeltesse! 4. A folyamatos termékfejlesztés következtében, a technikai adatok, illetve a külső megjelenés változhat!

A nem rendeltetésszerű használatból eredő károkért a gyártó / forgalmazó nem vállal felelősséget. Különösen abban az esetben, amennyiben bebizonyosodik, hogy a terméket vagy az elektronikat módosították, átalakították, a javításhoz nem az eredeti alkatrészeket használták, vagy ha a kár gondatlanságból vagy rongálás miatt következett be.

KÖRNYEZETVÉDELMI FIGYELMEZTETÉSEK: Amennyiben a termék javíthatatlannal meghibásodik, illetve élettartama végehez ér, tilos a háztartási hulladékokban elhelyezni! Kérjük, keresse fel az elektronikai hulladékok számára kijelölt gyűjtőhelyet és ott helyezze el a készüléket. A terméket, annak csomagolását és a használati utasításban feltüntetett ikon is erre figyelmezteti Önt. Az anyagok újra felhasználhatóak, azok jelölése szerint. A régi készülékek újra hasznosításával jelentősen hozzájárulunk a környezet védelméhez.

